State Feedback Control

Xu Chen

University of Washington



Motivation

- At the center of designing control systems is the idea of feedback.
- ▶ In such transfer-function approaches as lead-lag and root locus methods, the primal goal is to achieve a proper map of closed-loop poles with output feedback.

Key questions:


- ▶ How much freedom do we have for state-space systems?
- ► Are there fundamental system properties that yield higher achievable performance?
- How to implement the design algorithms?

General feedback structure

Consider an *n*-dimensional state-space system

$$\Sigma: \left\{ egin{array}{ll} \dot{x}(t) &=& Ax(t) + Bu(t) \ y(t) &=& Cx(t) + Du(t) \end{array}
ight. \quad x(t_0) = x_0$$

where $x \in \mathbb{R}^n$, $u \in \mathbb{R}^r$, and $y \in \mathbb{R}^m$.




state-feedback law:

$$u = -Kx + v \tag{1}$$

- v: new input
- $K \in \mathbb{R}^{r \times n}$: *n*-number of states, *r*-number of inputs

Goal



closed-loop system:

$$\Sigma_{cl}: \left\{ \begin{array}{ll} \dot{x}(t) &=& (A-BK)x(t)+Bv(t)\\ y(t) &=& (C-DK)x(t)+Dv(t) \end{array} \right. \quad x(t_0) = x_0 \quad (2)$$

- \triangleright key closed-loop property: eigenvalues of A-BK.
- ▶ How freely can we place the eigenvalues of $A_{cl} = A BK$?

Fact: If $\Sigma = (A, B, C, D)$ is in controllable canonical form, we can completely change all the eigenvalues of A - BK by choice of state-feedback gain matrix K.

▶ Problem setup: single-input single-output system in c.c.f.

$$H(s) = \frac{\beta_{n-1}s^{n-1} + \cdots + \beta_1s + \beta_0}{s^n + \alpha_{n-1}s^{n-1} + \cdots + \alpha_1s + \alpha_0} + d, \quad \Sigma = \left[\begin{array}{c|c} A & B \\ \hline C & D \end{array} \right]$$

$$A = \begin{bmatrix} 0 & 1 & 0 & \dots & 0 \\ 0 & 0 & 1 & 0 & \vdots \\ \vdots & \ddots & \ddots & \ddots & 0 \\ 0 & \dots & \dots & 0 & 1 \\ -\alpha_0 & \dots & \dots & -\alpha_{n-2} & -\alpha_{n-1} \end{bmatrix}, \ B = \begin{bmatrix} 0 \\ \vdots \\ 0 \\ 1 \end{bmatrix}$$

$$C = \begin{bmatrix} \beta_0 & \beta_1 & \dots & \beta_{n-1} \end{bmatrix}, \ D = d$$

$$\det(sI - A) = s^n + \alpha_{n-1}s^{n-1} + \dots + \alpha_1s + \alpha_0$$
 (3)

Goal: achieve desired closed-loop eigenvalue locations p_1, \dots, p_n , i.e.

$$\det(sI - (A - BK)) = (s - p_1)(s - p_2) \cdots (s - p_n)$$

$$= s^n + \gamma_{n-1} s^{n-1} + \cdots + \gamma_1 s + \gamma_0$$
(5)

▶ Let $K = [k_0, k_1, ..., k_{n-1}]$. The structured A and B give

$$BK = \begin{bmatrix} 0 \\ 0 \\ \vdots \\ 0 \\ 1 \end{bmatrix} \begin{bmatrix} k_0, k_1, \dots, k_{n-1} \end{bmatrix} = \begin{bmatrix} 0 & 0 & 0 & \dots & 0 \\ 0 & 0 & 0 & 0 & \vdots \\ \vdots & \dots & \ddots & \ddots & 0 \\ 0 & \dots & \dots & 0 & 0 \\ k_0 & \dots & \dots & k_{n-2} & k_{n-1} \end{bmatrix}$$

$$A - BK = \begin{bmatrix} 0 & 1 & 0 & \dots & 0 \\ 0 & 0 & 1 & 0 & \vdots \\ \vdots & \dots & \ddots & \vdots \\ 0 & \dots & \dots & 0 & 1 \\ -\alpha_0 - k_0 & \dots & \dots & -\alpha_{n-2} - k_{n-2} & -\alpha_{n-1} - k_{n-1} \end{bmatrix}$$

$$\begin{array}{c|ccccc}
\hline
A \\
\hline
\begin{bmatrix}
0 & 1 & 0 & \dots \\
\vdots & \ddots & 1 & \vdots \\
0 & \dots & 0 & 1 \\
-\alpha_0 & \dots & \dots & -\alpha_{n-1}
\end{bmatrix} \\
\hline
\det (sI - A) \\
\hline
s^n + \alpha_{n-1}s^{n-1} + \dots + \alpha_1s + \alpha_0
\end{array}$$

Α	A – BK							
0 1 0	0 1 0							
1 1	: 0							
0 0 1	0 0 1							
$\begin{bmatrix} -\alpha_0 & \dots & -\alpha_{n-1} \end{bmatrix}$	$\begin{bmatrix} -\alpha_0 - k_0 & \dots & -\alpha_{n-1} - k_{n-1} \end{bmatrix}$							
$\det\left(sI-A ight)$								
$s^n + \alpha_{n-1}s^{n-1} + \cdots + \alpha_1s + \alpha_0$								

A						A – BK			
	0	1	0			0	1	0	
			1						0
	0		0	1		0		0	1
	$-\alpha_0$			$-\alpha_{n-1}$		$\left[-\alpha_{0}-k\right]$	0		$-\alpha_{n-1}-k_{n-1}$
$\det\left(sI-A ight)$						$\det\left(sI-(A-BK) ight)$			
s ⁿ	$s^{n} + \alpha_{n-1}s^{n-1} + \cdots + \alpha_{1}s + \alpha_{0}$ $s^{n} + (\alpha_{n-1} + k_{n-1})s^{n-1} + \cdots + (\alpha_{0} + k_{0})$								

Goal (recap): achieve desired closed-loop eigenvalue locations p_1, \dots, p_n , i.e.

$$\det(sI - (A - BK)) = (s - p_1)(s - p_2) \cdots (s - p_n)$$

= $s^n + \gamma_{n-1}s^{n-1} + \cdots + \gamma_1s + \gamma_0$

$$\det\left(sI - (A - BK)\right) = s^n + \underbrace{\left(\alpha_{n-1} + k_{n-1}\right)}_{\text{target: } \gamma_{n-1}} s^{n-1} + \cdots + \underbrace{\left(\alpha_0 + k_0\right)}_{\text{target: } \gamma_0}$$

hence

$$k_0 = \gamma_0 - \alpha_0$$

$$\vdots$$

$$k_{n-1} = \gamma_{n-1} - \alpha_{n-1}$$

Eigenvalue-placement Algorithm

- 1 determine desired eigenvalue locations p_1, \dots, p_n
- 2 calculate desired closed-loop characteristic polynomial

$$(s-p_1)(s-p_2)\cdots(s-p_n)=s^n+\gamma_{n-1}s^{n-1}+\cdots+\gamma_1s+\gamma_0$$

3 calculate open-loop characteristic polynomial

$$\det(sI - A) = s^n + \alpha_{n-1}s^{n-1} + \cdots + \alpha_1s + \alpha_0$$

4 define the matrices:

$$K = [\gamma_0 - \alpha_0, \dots, \gamma_{n-1} - \alpha_{n-1}]$$

Powerful result: if the system is in controllable canonical form, we can arbitrarily place the closed-loop eigenvalues by state feedback!

General eigenvalue placement by state feedback

- What if the given state-space realization $\Sigma = (A, B, C, D)$ is not in the required form?
- ▶ We can then transform it to c.c.f. via a similarity transformation.
- **Powerful fact**: if system $\Sigma = (A, B, C, D)$ is controllable, then we can arbitrarily place the closed-loop eigenvalues via state feedback.

Discrete-time case

- the eigenvalue assignment of discrete-time systems is analogous:
 - system dynamics:

$$x(k+1) = Ax(k) + Bu(k)$$
$$y(k) = Cx(k)$$

- ightharpoonup controller: u(k) = -Kx(k) + v(k)
- closed-loop dynamics:

$$x(k+1) = Ax(k) - BKx(k) + Bv(k) = (A - BK)x(k) + Bv(k)$$

 arbitrary closed-loop eigenvalue assignment if system is controllable

Numerical example

$$x(k+1) = \begin{bmatrix} 1 & 1 & -2 \\ 0 & 1 & 1 \\ 0 & 0 & 1 \end{bmatrix} x(k) + \begin{bmatrix} 1 \\ 0 \\ 1 \end{bmatrix} u(k)$$
$$y(k) = \begin{bmatrix} 2 & 0 & 0 \end{bmatrix} x(k)$$

```
%MATLAB

A = [1,1,-2;0,1,1;0,0,1];

B = [1;0;1];

p = [0;0.1;0.2];

K = place(A, B, p)
```

#Python import control as ct import numpy as np A = np.array([[1,1,-2],[0,1,1],[0,0,1]]) B = np.array([[1],[0],[1]]) p = [0,0.1,0.2] K = ct.place(A, B, p) print(K)

The case with output feedback

- if the full state is not measurable, state feedback control is not feasible
- consider output feedback

$$\begin{cases} \dot{x} = Ax + Bu \\ y = Cx \Rightarrow \dot{x} = Ax - BFy + Bv = (A - BFC)x + Bv \\ u = -Fy + v \end{cases}$$

- \triangleright A BFC not as structured as A BK
- ▶ arbitrary closed-loop eigenvalue assignment not feasible

The case with output feedback

Example

Controllable mass-spring-damper system

$$\frac{d}{dt} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ -\frac{k}{m} & -\frac{b}{m} \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 \\ \frac{1}{m} \end{bmatrix} u$$

$$u^* \triangleq \frac{u}{m} \begin{bmatrix} 0 & 1 \\ -\frac{k}{m} & -\frac{b}{m} \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 \\ 1 \end{bmatrix} u^*$$

- ▶ arbitrary closed-loop eigenvalue assignment if $u^* = -k_1x_1 k_2x_2$, namely $U^*(s) = -k_1X_1(s) k_2X_2(s) = -(k_1 + k_2s)X_1(s) \Rightarrow$ a proportional plus derivative (PD) control law
- if with only proportional control, $u^* = -k_1x_1$, arbitrary closed-loop eigenvalue assignment is not possible